V40 (13-), 2014

Maintenance service

Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**	**11**	**12**	**13**
	km x 1000:	**30**	**60**	**90**	**120**	**150**	**180**	**210**	**240**	**270**	**300**	**330**	**360**	**390**
	miles x 1000:	**18**	**36**	**54**	**72**	**90**	**108**	**126**	**144**	**162**	**180**	**198**	**216**	**234**
Automatic transmission control - check the park / neutral position (PNP) switch		x	x	x	x	x	x	x	x	x	x	x	x	x
Parking brake - check and adjust		x	x	x	x	x	x	x	x	x	x	x	x	x
External lighting -check the function		x	x	x	x	x	x	x	x	x	x	x	x	x
Horn - check the signal		x	x	x	x	x	x	x	x	x	x	x	x	x
Headlamp/fog lamp - check and align headlamps		x	x	x	x	x	x	x	x	x	x	x	x	x
Washers and wipers for windshields and headlamps - check the function and for signs of wear		x	x	x	x	x	x	x	x	x	x	x	x	x
Seat belts - check the function and for signs of wear		x	x	x	x	x	x	x	x	x	x	x	x	x
Vehicle with camera for collision warning - clean the inside of the windscreen in front of the camera lens		x	x	x	x	x	x	x	x	x	x	x	x	x
Vehicles with alcolock - calibrate	Calibration must be performed once a year, when the information text in the display indicates this.													
Air cleaner (ACL) passenger compartment -replace		x	x	x	x	x	x	x	x	x	x	x	x	x
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**	**11**	**12**	**13**
	km x 1000:	**30**	**60**	**90**	**120**	**150**	**180**	**210**	**240**	**270**	**300**	**330**	**360**	**390**
	miles x 1000:	**18**	**36**	**54**	**72**	**90**	**108**	**126**	**144**	**162**	**180**	**198**	**216**	**234**
Raise the vehicle														
Engine, transmission, transmission -check for leaks	In event of leakage from the transmission, check the oil	x	x	x	x	x	x	x	x	x	x	x	x	x

	level.													
Engine oil, oil filter - change oil and oil filter		x	x	x	x	x	x	x	x	x	x	x	x	x
Automatic transmission The oil does not normally need changing. The oil must be changed if instructed to do so in the display	**For vehicles used as taxis or primarily used with a trailer, change the oil according to the service program.**		x		x		x		x		x		x	
Wheels and tires (excluding spare wheel) - check for damage, wear, tire pressure		x	x	x	x	x	x	x	x	x	x	x	x	x
Drive shafts -check the play -check rubber bellows			x		x		x		x		x		x	
Brake pads, brake discs - check	Brake pads, front, check	x	x	x	x	x	x	x	x	x	x	x	x	x
Brake and fuel lines and fuel filter - check for leakage and damage			x		x		x		x		x		x	
External fuel filter, In markets with contaminated fuel: -replace	**Max. 25,000 km** replacement interval. More frequent replacement may be necessary in some markets.													
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**	**11**	**12**	**13**
	km x 1000:	**30**	**60**	**90**	**120**	**150**	**180**	**210**	**240**	**270**	**300**	**330**	**360**	**390**
	miles x 1000:	**18**	**36**	**54**	**72**	**90**	**108**	**126**	**144**	**162**	**180**	**198**	**216**	**234**
Front suspension, steering system - check for wear according to: Wheel angles check			x		x		x		x		x		x	
Rear wheel suspension - check for wear according to: Wheel angles check			x		x		x		x		x		x	
AWD: Final drive, bevel gear -check for leaks	Only check the oil level if there is leakage.		x		x		x		x		x		x	
AWD: Propeller shaft, pilot bearing, universal joint -check for signs of			x		x		x		x		x		x	

wear														
Lower the vehicle														
Air cleaner (ACL), engine -replace	Clean the air cleaner (ACL) housing. **Change only according to km/miles interval.**		x		x		x		x		x		x	
Spark plugs -replace	**Change only according to km/miles interval.**				x				x				x	
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**	**11**	**12**	**13**
	km x 1000:	**30**	**60**	**90**	**120**	**150**	**180**	**210**	**240**	**270**	**300**	**330**	**360**	**390**
	miles x 1000:	**18**	**36**	**54**	**72**	**90**	**108**	**126**	**144**	**162**	**180**	**198**	**216**	**234**
Fluid levels - engine compartment - check and adjust the brake fluid, clutch fluid, washer fluid. coolant		x	x	x	x	x	x	x	x	x	x	x	x	x
Engine coolant - check and adjust the antifreeze/corrosion protection rating		x	x	x	x	x	x	x	x	x	x	x	x	x
Vehicles with temporary tire sealing kit - check sealant container - replace every four years (see decal)														
Auxiliaries belts, belt tensioner -replace according to the service program or: - replace at a **maximum 10 year** interval							x						x	
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**	**11**	**12**	**13**
	km x 1000:	**30**	**60**	**90**	**120**	**150**	**180**	**210**	**240**	**270**	**300**	**330**	**360**	**390**
	miles x 1000:	**18**	**36**	**54**	**72**	**90**	**108**	**126**	**144**	**162**	**180**	**198**	**216**	**234**
Timing belt, belt tensioner, idler pulley -replace according to the service program or: - replace at a **maximum 10 year** interval							x						x	
Brake fluid -replace	Recommend that a customer													

	with normal mileage has the fluid replaced every other year.		x		x		x		x		x		x	
	The oil must be changed every year if the car is used for mountain driving or is mainly used in humid climates.	x	x	x	x	x	x	x	x	x	x	x	x	x
SRI - set the service reminder indicator (SRI) to zero	According to: Resetting service message	x	x	x	x	x	x	x	x	x	x	x	x	x