V50, 2008

Maintenance service

Program point:	year:	1	2	3	4	5	6	7	8	9	10	11	12	13
	km x 1000:	30	60	90	120	150	180	210	240	270	300	330	360	390
	miles x 1000:	18	36	54	72	90	108	126	144	162	180	198	216	234
Automatic transmission control -check the park / neutral position (PNP) switch		x	x	x	x	x	x	x	x	x	x	x	x	x
Parking brake -check and adjust		x	x	x	x	x	x	x	x	x	x	x	x	x
External lighting -check the function		x	x	x	x	x	x	x	x	x	x	x	x	x
Horn - check the signal		x	x	x	x	x	x	x	x	x	x	x	x	x
Headlamp/fog lamp -check and align headlamps		x	x	x	x	x	x	x	x	x	x	x	x	x
Washers and wipers for windshields and headlamps -check the function and for signs of wear		x	x	x	x	x	x	x	x	x	x	x	x	x
Seat belts -check the function and for signs of wear		x	x	x	x	x	x	x	x	x	x	x	x	x
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**	**11**	**12**	**13**
	km x 1000:	**30**	**60**	**90**	**120**	**150**	**180**	**210**	**240**	**270**	**300**	**330**	**360**	**390**
	miles x 1000:	**18**	**36**	**54**	**72**	**90**	**108**	**126**	**144**	**162**	**180**	**198**	**216**	**234**
Raise the vehicle														
Engine, transmission, transmission -check for leaks	In case of leakage, check the oil level.	x	x	x	x	x	x	x	x	x	x	x	x	x
Engine oil, oil filter - change oil and oil filter		x	x	x	x	x	x	x	x	x	x	x	x	x
Automatic transmission The oil does not normally need changing. The oil must be changed if instructed to do so in the display	**For vehicles used as taxis or primarily used for towing, change the oil according to the service program.**		x		x		x		x		x		x	
Wheels and tires (excluding spare wheel) - check for		x	x	x	x	x	x	x	x	x	x	x	x	x

damage, wear, tire pressure														
Drive shafts -check the play -check rubber bellows			x		x		x		x		x		x	
Brake pads, brake discs - check	Brake pads, front, check Brake pads, rear, check	x	x	x	x	x	x	x	x	x	x	x	x	x
Brake and fuel lines and fuel filter -check for leakage and damage			x		x		x		x		x		x	
External fuel filter, In markets with contaminated fuel: -replace	**Max. 25 000 km** replacement interval. More frequent replacement may be necessary in some markets.													
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**	**11**	**12**	**13**
	km x 1000:	**30**	**60**	**90**	**120**	**150**	**180**	**210**	**240**	**270**	**300**	**330**	**360**	**390**
	miles x 1000:	**18**	**36**	**54**	**72**	**90**	**108**	**126**	**144**	**162**	**180**	**198**	**216**	**234**
Front suspension, steering system -check for signs of wear			x		x		x		x		x		x	
Rear wheel suspension -check for signs of wear			x		x		x		x		x		x	
AWD: Final drive, bevel gear -check for leaks	Only check the oil level if there is leakage.		x		x		x		x		x		x	
AWD: Propeller shaft, pilot bearing, universal joint -check for signs of wear			x		x		x		x		x		x	
Lower the vehicle														
Air cleaner (ACL), engine -replace	Clean the air cleaner (ACL) housing.		x		x		x		x		x		x	
Spark plugs -replace					x				x				x	
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**	**11**	**12**	**13**
	km x 1000:	**30**	**60**	**90**	**120**	**150**	**180**	**210**	**240**	**270**	**300**	**330**	**360**	**390**
	miles x 1000:	**18**	**36**	**54**	**72**	**90**	**108**	**126**	**144**	**162**	**180**	**198**	**216**	**234**
Fluid levels - engine compartment -check and adjust the brake fluid, clutch fluid, washer fluid. coolant		x	x	x	x	x	x	x	x	x	x	x	x	x
Engine coolant - check and adjust the		x	x	x	x	x	x	x	x	x	x	x	x	x

antifreeze/corrosion protection rating														
Battery - check: poles, electrolyte level, mounting			x		x		x		x		x		x	
Vehicles with temporary tire sealing kit - check sealant container - replace every four years (see decal)														
Auxiliaries belts -replace according to the service program or: - replace at a **maximum 10 year** interval	Applies only to B52x4x						x						x	
Program point:	**year:**	**1**	**2**	**3**	**4**	**5**	**6**	**7**	**8**	**9**	**10**	**11**	**12**	**13**
	km x 1000:	**30**	**60**	**90**	**120**	**150**	**180**	**210**	**240**	**270**	**300**	**330**	**360**	**390**
	miles x 1000:	**18**	**36**	**54**	**72**	**90**	**108**	**126**	**144**	**162**	**180**	**198**	**216**	**234**
Timing belt, belt tensioner, idler pulley -replace according to the service program or: - replace at a **maximum 10 year** interval	Applies only to B52x4x						x						x	
Air cleaner (ACL) passenger compartment -replace		x	x	x	x	x	x	x	x	x	x	x	x	x
Roof system C70 - check - lubrication	See: Service program/838 Convertible roof/Service roof system	x	x	x	x	x	x	x	x	x	x	x	x	x
Brake fluid -replace	Recommend that a customer with normal mileage has the fluid replaced every other year.		x		x		x		x		x		x	
	The fluid must be replaced every year if the car is used for mountain driving or is mainly used in humid climates.	x	x	x	x	x	x	x	x	x	x	x	x	x
SRI - set the service reminder indicator (SRI) to zero	See Resetting the service reminder	x	x	x	x	x	x	x	x	x	x	x	x	x

	indicator (SRI)													