

The oil does not normally need changing.	used as taxis or primarily used for towing, the oil should be changed as indicated in the service program. AW50-42, see Gearbox fluid, replacing . AW55-50, see Gearbox fluid, replacing .										
Program point C70/S70/V70	Year:	1	2	3	4	5	6	7	8	9	10
Gasoline engines	Km x 1000:	10	30	50	70	90	110	130	150	170	190
	Miles x 1000:	6	18	30	42	54	66	78	90	102	114
Wheels and tires -check for damage and signs of wear			x	x	x	x	x	x	x	x	x
Drive shafts -check the play -check rubber bellows			x	x	x	x	x	x	x	x	x
Brake lining, brake discs -check	Minimum brake lining thickness: Front.....3 mm/0.12" Rear.....2 mm = 0.08" Check brake disc thickness and condition when replacing the brake lining.		x	x	x	x	x	x	x	x	x
Brake and fuel lines and fuel filter -check for leakage and damage			x	x	x	x	x	x	x	x	x
Fuel filter -replace									x		
Exhaust system -condition, leakage, mounting.						x	x	x	x	x	x
Raise the front wheels											
Program point C70/S70/V70	Year:	1	2	3	4	5	6	7	8	9	10
Gasoline engines	Km x 1000:	10	30	50	70	90	110	130	150	170	190
	Miles x	6	18	30	42	54	66	78	90	102	114

parameter	conditions for service . See Checking engine time conditions for service											
-----------	---	--	--	--	--	--	--	--	--	--	--	--