





<b>AWD: Final drive, bevel gear</b> - check for leaks	Only check the oil level if there is leakage		x		x		x		x		x		x	
<b>AWD: Propeller shaft, pilot bearing, universal joint</b> - check for signs of wear			x		x		x		x		x		x	
<b>Lower the vehicle</b>														
<b>Program point:</b>	<b>year:</b>	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>	<b>10</b>	<b>11</b>	<b>12</b>	<b>13</b>
	<b>km x 1000:</b>	<b>30</b>	<b>60</b>	<b>90</b>	<b>120</b>	<b>150</b>	<b>180</b>	<b>210</b>	<b>240</b>	<b>270</b>	<b>300</b>	<b>330</b>	<b>360</b>	<b>390</b>
	<b>miles x 1000:</b>	<b>18</b>	<b>36</b>	<b>54</b>	<b>72</b>	<b>90</b>	<b>108</b>	<b>126</b>	<b>144</b>	<b>162</b>	<b>180</b>	<b>198</b>	<b>216</b>	<b>234</b>
<b>Air cleaner (ACL) engine</b> - replace	Clean the air cleaner (ACL) housing.  <b>Change only according to km/miles interval.</b>		x		x		x		x		x		x	
<b>Fluid levels - engine compartment</b> - check and adjust the brake fluid, clutch fluid, power steering fluid, washer fluid. coolant		x	x	x	x	x	x	x	x	x	x	x	x	
<b>Engine coolant</b> - check and adjust the antifreeze/corrosion protection rating		x	x	x	x	x	x	x	x	x	x	x	x	
<b>Vehicles with temporary tire sealing kit</b> - check sealant container - replace every four years (see decal)														
<b>Program point:</b>	<b>year:</b>	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>	<b>10</b>	<b>11</b>	<b>12</b>	<b>13</b>
	<b>km x 1000:</b>	<b>30</b>	<b>60</b>	<b>90</b>	<b>120</b>	<b>150</b>	<b>180</b>	<b>210</b>	<b>240</b>	<b>270</b>	<b>300</b>	<b>330</b>	<b>360</b>	<b>390</b>
	<b>miles x 1000:</b>	<b>18</b>	<b>36</b>	<b>54</b>	<b>72</b>	<b>90</b>	<b>108</b>	<b>126</b>	<b>144</b>	<b>162</b>	<b>180</b>	<b>198</b>	<b>216</b>	<b>234</b>
<b>Outer accessory drive belt and mechanical belt tensioner</b> - replace according to the service program or: - replace at max. 10 year intervals	For engine No.: -884797		x				x			x			x	
<b>Outer accessory drive belt</b> (with hydraulic belt tensioner) -replace the belt according to the service program, or: - replace the belt at	From engine No.: 884798-1046801			x			x			x			x	



